

**STUART**

## Installation, Operation & Maintenance Instructions

Please leave this instruction booklet with the owner as it contains important guarantee, maintenance and safety information



**Read this manual carefully before commencing installation.**

This manual covers the following products:

**Jet 55-45 PS**  
Pt. No. 46617

**Jet 80-45 PS**  
Pt. No. 46618

**50 Hz**



**PRODUCT DESCRIPTION**

Electric motor driven centrifugal pump complete with an automatic control system, consisting of flow switch, pressure switch, pressure vessel and electronic control.

**APPLICATION**

The Jet Pressure Set range is designed for pressure boosting applications in vented stored, cold clean water systems, where under gravity, no flow is available and can be used in systems where a negative head exists.

**Inlet pressures to the pump and ambient temperatures must not exceed the values given in the technical specifications.**

**STORAGE**

If this product is not to be installed immediately on receipt, ensure that it is stored in a dry, frost and vibration free location in its original packaging.

<b>CONTENTS</b>	<b>Page</b>
Checklist .....	5
Important Facts – read before commencing installation .....	6
Location .....	7
Pump Connections .....	9
Electrical Installation .....	10
Commissioning .....	13
Maintenance .....	14
Technical Specification .....	16
Trouble Shooting .....	18
Guarantee .....	21

## **WARNINGS:**



- This pump set must not be used for any other application without the written consent of Stuart Turner Limited and in particular, must not be connected directly to the mains water supply.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Maximum head (closed valve) Jet 55–45 PS-45 metres, Jet 80–45 PS-45 metres.
- The motor casing can become very hot under normal operating conditions. Care must be taken to ensure it cannot be touched during operation.




- The electrical installation must be carried out in accordance with the current national electrical regulations.
- The electrical installation must be installed by a qualified person.
- In the interests of electrical safety a 30 mA residual current device (R.C.D. not supplied) should be installed in the supply circuit. This may be part of a consumer unit or a separate unit.
- Before starting work on the electrical supply ensure power supply is isolated.
- DO NOT allow the supply cord to contact hot surfaces, including the motor shell, pump body or pipework. The cord should be safely routed and secured by cable clips.



- This appliance must be earthed via the supply cord, which must be correctly connected to the earth point located in the terminal box.
- The supply cord and internal wiring within the terminal box are routed and secured to ensure compliance with the electrical standard EN 60335-1. It is essential that prior to any disturbance of this internal wiring, all cable routing and securing details are carefully noted to ensure re-assembly to the same factory pattern is always maintained.
- If the supply cord is to be changed or is damaged, it must be replaced with a special cord assembly available from Stuart Turner or one of their approved repairers.

Please read installation details carefully as they are intended to ensure this product provides long, trouble free service. Failure to install the unit in accordance with the installation instructions will lead to invalidation of the warranty.

CHECKLIST



Item	Description	Qty	Item	Description	Qty
(A)	Pump	1	(D)	Pressure vessel	1
(B)	Hose & sealing washer	2	(E)	Outlet connector & 'O'-ring	1
(C)	Inline strainer	1	(F)	Mounting feet & fittings	4

Your product may vary slightly from the picture above.  
Note: Item E supplied loose, this will require fitting to the pump outlet. Tighten to torque 4/5 Nm.

## 1 IMPORTANT FACTS: READ BEFORE COMMENCING PUMP INSTALLATION

### A Water storage capacity.

- 1.11 The cold water storage capacity must be sufficient to meet the flow rates required by the pumped equipment and any other water using fittings and appliances, which may be operated simultaneously.
- 1.12 Ensure the pump is primed as described in the priming section before starting, damage to the shaft seal will result otherwise. See Section 5 – Commissioning.

### B Water temperature

This unit is designed to pump cold water only which should not exceed the following values:

- 1.13 The maximum allowable water temperature is 35 °C.
- 1.14 The minimum allowable water temperature is 4 °C.

### C Pipework – General

- 1.15 **Secure pipework:** Ensure pipework to and from pump is independently supported & clipped to prevent forces being transferred to inlet and outlet branches of pump.
- 1.16 **Flux:** Solder joints must be completed and flux residues removed prior to pump installation (**flux damage will void any warranty**).
- 1.17 **Pipework design:** Care should be taken in the design of pipework runs to minimize the risk of air locks e.g. use drawn bends rather than 90° bends.



- 1.18 **DO NOT** introduce solder flux to pumps or pump parts manufactured from plastic.

- 1.19 **DO NOT** allow contact with oil or cellulose based paints, paint thinners or strippers, acid based descalents or aggressive cleaning agents.



- 1.20 **DO NOT** install a non-return valve, or devices which contain non-return valves, in the suction (inlet) pipework to the pump. The pump must be free to vent to the supply tank at all times.

- 1.21 **DO NOT** connect this pump to the mains water supply.

### D Plumbing Installation Regulations

- 1.22 The plumbing installation must comply with the current water and building regulations.
- 1.23 The plumbing installation must be installed by a qualified person.

### E Pressure vessel

- 1.24 Pressure vessel is charged at the factory see Section 6 – Maintenance for details.

## 2 LOCATION – GENERAL



- 2.11 **Access:** For emergencies and maintenance the pump must be easily accessible.
- 2.12 **Protection:** The pump must be located in a dry position, frost free and protected from freezing, particularly when installed in a loft (not recommended).
- 2.13 **Ventilation:** Ensure an adequate air flow to cool the pump. Separate the pump from other appliances that generate heat. An 80 mm (3 ") air gap must be maintained around the pump.
- 2.14 **Safety:** The motor casing can become very hot under normal operating conditions. Care must be taken to ensure it cannot be touched during operation.
- 2.15 **Water retention:** Site the pump in a location where in the unlikely event of a water leak, any spillage is contained or routed to avoid electrics or areas sensitive to water damage.
- 2.16 **Static inlet pressure:** Before deciding where to locate the unit check to ensure the static inlet head between pump and the bottom of the cold water tank (Fig. 2) is at least 1 metre and does not exceed the max inlet head of 5 metres.
- 2.17 **Ambient temperature:** The pump must be sited in a location where the maximum ambient temperature does not exceed 40 °C.
- 2.18 **Pipework:** For optimum performance pipework 28 mm should be used. 22 mm is acceptable, however, any pipe size reduction will reduce the pumps performance.
- 2.19 **Static outlet pressure:** The static outlet head (Fig. 2) must also be within the maximum requirement of 13 metres.
- 2.20 **Noise:** The anti-vibration mounting feet and flexible hoses have been supplied as standard, and a precaution to reduce noise transmission, however care must be taken when mounting the pump that any noise is not amplified through loose panels or pipework. **Do not screw down the pump.**
- 2.21 **Direction of flow:** Ensure the water flow is in the direction of the arrow marked on the flow switch reed clamp (vertically upwards).
- 2.22 **Isolating valves:** If permanently installed, isolating valves should be fitted in suction and delivery pipework to enable easy isolation and access to the pump.
- 2.23 **Flexible hoses:** Only use the Stuart Turner hose set supplied with the pump.
- 2.24 **Preferred pump location:** The preferred pump location is at floor level next to the water source or a level that is below the secondary tapping that feeds the pump. Ensure the pump is mounted in a position that allows easy access to the terminal box if required. The pump location is also dependent on limitations of the static inlet and outlet heads of the installation.

## 2 LOCATION – PUMP MOUNTED BELOW WATER SOURCE




Fig. 2

2.25 **The cold water supply: Must be a DEDICATED AIR FREE** supply via a tank connector.

**Do not connect to the mains.**

Cont ...



### 3 PUMP CONNECTIONS

- 3.11 **Hose to pump:** These pumps have G 1 threaded connections to accept the hoses supplied. The hose end is made water tight with a sealing washer on assembly, nip tight to 4/5 Nm for water tight seal (**Do not overtighten**).
- 3.12 **Hose to pipework:** Hoses terminating in G 1 threaded connections are supplied and when securing the male end to a suitable pipe fitting, seal with PTFE tape or other suitable sealant.

## 4 ELECTRICAL INSTALLATION / EARTHING



- 4.11 **Regulations:** The electrical installation must be carried out in accordance with the current national electrical regulations and installed by a qualified person.
- 4.12 **Safety:** In the interests of electrical safety a 30 mA residual current device (**R.C.D. not supplied**) should be installed in the supply circuit. This may be part of a consumer unit or a separate unit.
- 4.13 Before starting work on the electrical supply ensure power supply is isolated.
- 4.14 **DO NOT** allow the supply cord to contact hot surfaces, including the motor shell, pump body or pipework. The cord should be safely routed and secured by cable clips.
- 4.15 **Supplementary Bonding:** The pressure set is factory fitted with a supplementary earthing wire to ensure continuity throughout the assembly (Fig. 3). It must be ensured throughout the product life that this electrical connection remains in place.




Fig. 3

- 4.16 **Adjacent pipes:** Adjacent suction and delivery pipes should be fitted with earthing clamps in accordance with current regulations (Fig. 4).




Fig. 4

- 4.17 **Earthing:** This appliance must be earthed via the supply cord, which must be correctly connected to the earth point located in the terminal box.
- 4.18 **Pipework:** Copper or metallic pipework must have supplementary earth bonding where the continuity has been broken by flexible hoses or plastic components.
- 4.19 **Additional earthing:** Certain installations may require additional earthing arrangements such as equipotential bonding. Reference should be made to the relevant regulations concerning this subject to ensure compliance.

4.20 **Connections:** The pump must be permanently connected to the fixed wiring of the mains supply using the factory fitted supply cord, this must be a fused spur off the ring main and **NOT** connected to the boiler or the immersion heater circuits.

#### 4.21 **Wiring of connection unit:**



**WARNING: This appliance must be earthed.**

The wires in the mains lead (supply cord) are coloured in accordance with the following code:

Green and Yellow: Earth

Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your connection unit proceed as follows:

- The wire which is coloured green and yellow must be connected to the terminal in the connection unit which is marked with the letter E or by the earth symbol: ⊕ or coloured green or green and yellow.
- The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.
- The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

#### 4.22 **Wiring Diagram:**



**The supply cord and internal wiring within the terminal box are routed and secured to ensure compliance with the electrical standard EN 60335-1. It is essential that any disturbance of this internal wiring is avoided and the factory routing and securing of all internal wiring is always maintained.**




Fig. 5

4.23 **Fuses:** The following fuse size should be used with the appropriate pump:

Model	Fuse Size (AMPS)
All Models	13

4.24 **Supply Cord Replacement:**



The supply cord and internal wiring within the terminal box are routed and secured to ensure compliance with the electrical standard EN 60335-1. It is essential that prior to any disturbance of this internal wiring, all cable routing and securing details are carefully noted to ensure re-assembly to the same factory pattern is always maintained.

If the supply cord is to be changed or is damaged, it must be replaced with a special cord assembly available from Stuart Turner or one of their approved repairers.

On disassembly note the cord retention and routing system. Re-assemble to the same pattern.

For information on cable connection consult the wiring diagram and cable gland fitting instructions.

4.25 **Cable Gland Fitting Instructions:**




Fig. 6

To enable correct assembly of the cable gland the 'O'-ring (Fig. 6 item 1) must be placed over the cable before the clamping insert (Fig. 6 item 2) can be tightened.

Note: Cable diameter range:- 8.3 mm to 10.7 mm.

4.26 **Supply Cord Extension:**

The pumps are fitted with a supply cord to the following specification:-  
All models. . . . .HO7RN-F3 G 1 mm<sup>2</sup> – 10 Amp rated cable.  
If the supply cord is to be extended, a cord of the same specification should be used. Any connections or junction boxes used should be specifically suited for the application and installed in accordance with the manufacturers instructions.

## 5 COMMISSIONING



### 5.11 System Flushing

The pipework system should be flushed out prior to the pump being connected to ensure any contaminants/chemical residues and foreign bodies are removed from elsewhere in the system.

**5.12 Water Supply:** Always ensure that water storage capacity is adequate to meet the demand. Ensure the pump chamber is full of water before starting the pump. Failure to do this could result in seal damage. To ensure dry running does not occur the pump must be primed as described in priming section below. **Do not run pump dry.**

**5.13 Priming:** Prior to switching the pump on and connecting the outlet hoses to the system pipework the pump chamber must be primed. The pump must be primed (filled with water) before starting. Turn on water supply, prime and vent the pump by unscrewing the priming plug (Fig. 7) slowly until all air escapes and water emerges. Re-tighten the plug.




Fig. 7

### 5.14 Starting the pump:

- Ensure all outlets are closed, turn power supply 'on' – pump will start, pressurise the system then stop.
- Open and close all outlets in turn associated with the pump, allowing water to flow from each outlet until all air is purged. As each outlet is opened and closed, the pump will start and stop respectively.  
Note: After closing the outlet there will be a small time delay before the pump stops, which is normal.
- Any tap or control valve within the system when opened and closed will now turn the pump on/off. Providing this is the case the system is now operating correctly.
- Carefully check pump and pipework for leaks whilst pump running and stationary before leaving the installation unattended.



- Do not run pump without guards and terminal box lid correctly fitted.**
- The pump chamber must be full of water at all times. Seal damage will result if the pump runs dry.**

**5.15 For further technical support:** Phone the Stuart Turner TechAssist team on +44 (0) 800 31 969 80. Our staff are trained to help and advise you over the phone.

## 6 MAINTENANCE



- 6.11 Turn off water supplies to the pump and release pressure by opening water outlets before attempting maintenance.

- 6.12 **Inlet strainer:** Incorporated in the strainer is a removable gauze filter which may require periodic cleaning. The frequency of this operation is dependent upon installation conditions.

The strainer is located in the inlet pipework to the pump (Fig. 8). The gauze filter is removed as follows:-

- Isolate pump electrically.
- Release all system pressure.
- Isolate water supply.
- Remove screwed hexagonal plug from strainer body taking care to collect or absorb any residual water (Fig. 8).





Fig. 8

- Remove and clean stainless steel gauze filter.
  - Reassemble gauze and secure plug tightly.
  - Turn on water supplies, connect power supply and test.
- 6.13 **Pressure vessel:** The pressure vessel should be checked once every 6 months to have its air charge checked or replenished, this should be carried out as follows:-
- Isolate pump electrically.
  - Isolate the water supply by closing the appropriate isolating valves.
  - Release system water pressure by opening an outlet on the system.
  - Disconnect hose fitted to pressure vessel.
  - Check air charge at Schrader valve (Fig. 9) using a tyre pressure gauge.
  - Replenish air charge by injecting air into the vessel via the Schrader valve using a car or bicycle pump (Fig. 9).
  - Re-connect hose to pressure vessel to achieve a water tight connection. Ensure rubber washer seal is in place.
  - Close all system outlets, open inlet and outlet isolating valves.
  - After maintenance is completed refer to Section 4 – Commissioning for instructions on re-starting pump.

Cont ...



Model	Air Precharge bar (psi)
All models	2.0 (29)

6.14 **Water scale:** As water is heated scale deposits are released in areas of hard water, scale can cause the mechanical seal to stick if left without use for long periods. The pump must be run for at least 5 minutes every four weeks to "exercise" all working parts. Run on cool water. See Section 7 – Technical Specification for note on water temperature. This particularly applies to guest bathrooms used infrequently.

6.15 **Cleaners, Disinfectants and Descalents:**



Acid based descalents and aggressive cleaning agents must not come into contact with the pump. The pump must be removed from the system prior to the use of these products. The system should be flushed to remove all chemicals before the pump is re-connected. If in any doubt as to the suitability of the chemical solutions, please contact our TechAssist helpline on +44 (0) 800 31 969 80.

## 7 TECHNICAL SPECIFICATION

Pump Model		Jet 55-45 PS 50 Hz 46617	Jet 80-45 PS 50 Hz 46618
General	Guarantee	1 year	
	Approvals	CE	
Features	Pump type	Centrifugal	
	Pump control	Pressure/flow switch	
	Dry run protection	✓	✓
	Diaphragm tank size	24 litres	
	Diaphragm tank capacity	12 litres	
	Built in 'no water' cut out	✓	✓
	Positive and negative head application	✓	✓
	Typical noise	68 dB(A)	72 dB(A)
Materials	Pump body	Stainless steel	
	Impeller	Plastic	
	Mechanical seal	EPDM / Carbon / Ceramic	
Performance	Maximum head – closed valve	4.5 bar / 45 metres	4.5 bar / 45 metres
	Performance @ 9 l/min	3.6 bar / 36 metres	3.7 bar / 37 metres
	Performance @ 50 l/min	0.3 bar / 3 metres	2.3 bar / 23 metres
	Maximum flow	55 l/min	80 l/min
	Minimum static inlet pressure	0.1 bar (1 metre)	
	Maximum static inlet pressure	0.5 bar (5 metres)	
	Maximum static outlet pressure	1.3 bar (13 metres)	
	Maximum working pressure*	500 kPa (5 bar)	
	Maximum ambient air temperature	40 °C	
	Min / Max water temperature	Min 4 °C / Max 35 °C	
	Cut out flow	1 l/min (approx)	
	Cut in pressure	180 kPa (1.8 bar)	
	Pressure vessel air pre-charge	2.0 bar (29 psi)	
	Maximum suction lift	5 metres	
Connections	Pump connections	G 1 female	
Motor	Type	Induction, auto-reset thermal trip	
	Duty rating	Continuous (S1)	
Electrical	Power supply (Vac/Ph/Hz)	230 V a.c. / 1 / 50 Hz	
	Power consumption – P1	640 Watts	925 Watts
	Current – full load	2.9 Amps	5.2 Amps
	Fuse rating	13 Amps	
	Power cable length	1.5 metres (pre-wired)	
Physical	Enclosure protection	IPX4	
	Length	521 mm	
	Width	280 mm	
	Height – excluding hoses	700 mm	
	Weight – including fittings	13.2 Kg	15.7 Kg

Stuart Turner reserve the right to amend the specification in line with its policy of continuous development of its products.

Cont ...



\*Note: Max working pressure is the maximum pressure that can be applied to the pump internal casing under any installation conditions.

- 7.11 **Noise:** The equivalent continuous A-weighted sound pressure level at a distance of 1 metre from the pump does not exceed 73 dB(A) for Jet 55–45 PS or 76 dB(A) for Jet 80–45 PS.

## 8 TROUBLE SHOOTING GUIDE

Symptoms	Probable Cause	Recommended Action
Pump will not start.	Electrical supply.	Check wiring connections. Check all switches are 'on'. Check fuse (see fuse section). Check circuit breaker is set.
	Failed reed switch/PCB/ pressure switch	Contact PumpAssist.
	Recommended static inlet/ outlet heads exceeded.	Re-position pump (see Section 2 – Location).
	Internal motor thermotrip activated.	Wait for thermotrip to cool and auto-reset and investigate cause of problem before re-starting.
	Water starvation to pump.	Refer to 'dry running' section.
Pump starts when outlets are off.	Leak in system.	Check tap washers, w/c valve washers, pipe joints.
or Pump cycles (hunts) on/off frequently.	Low charge pressure in pressure vessel.	Check charge pressure in pressure vessel (see Section 5 – Maintenance).
	Debris under non-return valve sealing face.	Run at full flow to try and flush away debris or remove, clean or replace non-return valve.
Pump runs on when all terminal outlets are closed.	Leak in system.	Check tap washers, w/c valve washers, pipe joints.
	Reed clamp out of position.	Ensure reed clamp is fitted correctly in location groove.
	Failed reed switch or P.C.B.	If pump continues to run, this indicates a closed circuit in either the flow switch reed or P.C.B. in the terminal box, these should be checked electrically.
	Jammed flow switch.	Isolate the pump electrically and hydraulically and remove brass housing that contains the float. Check float for free movement.
Pump runs, but no water.	Pump air locked	Remove priming plug, fill with water. Refit plug.
	Water supply low.	Check water level in the supply tank or well and all stopcocks are open. Check outlet not restricted or blocked.
	Air bubbles in suction pipe.	Check connections are all airtight.
Reduced flow/performance.	Blocked shower head spray plate.	Clean in accordance with manufacturers instructions.
	Blocked pipework or pump.	Isolate pump electrically and hydraulically, locate blockage and remove.
Flexible hose leaks	Not fitted correctly.	Check that the hose is pushed firmly onto the pump inlet/ outlet connections and pipework.
	Damaged 'O'-rings.	Check copper pipe ends are cleanly cut and deburred.

Cont ...

### 8.11 **Dry Run Protection:**

This pump is fitted with a safety control circuit, which will detect the following fault condition:

- **Dry running caused by water starvation to the pump.**

Should the pump run out of water it will stop as part of a "protective logic sequence", detailed below.

The fault should be rectified before re-starting the pump. Check that there is sufficient water supply to the pump and also ensure that all terminal fitting outlets are closed.

### 8.12 **Protective Logic Sequence:** If water starvation occurs and the power supply to the pump remains uninterrupted, the pump controller will perform the following protective sequence.

- 1) If the pump detects water starvation, it will stop operation after a 1 minute period.
- 2) The pump will remain in the off condition for a period of 5 minutes.
- 3) The pump will then re-start and if the water starvation condition remains present, the pump will then stop operation after a 1 minute period.
- 4) The pump will remain in the off condition for a period of 5 minutes.
- 5) The pump will then re-start and if the water starvation condition remains present, the pump will then stop operation after a 1 minute period.
- 6) The pump will remain in the off condition for a period of 5 minutes.
- 7) The pump will then re-start and if the water starvation condition remains present, the pump will then stop operation after a 1 minute period.
- 8) After three consecutive resets are performed the pump will remain in the off condition indefinitely.
- 9) To restart the pump, the power supply should be first isolated for a period of at least 10 seconds before switching on again.

If the pump fails to operate normally after three attempts to re-start, then please consult Stuart Turner TechAssist +44 (0) 800 31 969 80.

### 8.13 **Fault Finding:** The PCB is also fitted with a "power on" indicator light. This will remain illuminated when mains power is supplied to the board. The indicator light is located on the PCB within the terminal box.



- **This operation should only be carried out by a competent person**

To view the light the following procedure must be followed:-

- Isolate the mains electrical power supply from the pump.
- Remove the four screws retaining the terminal box lid (Fig. 10).
- Lift the terminal box lid off.
- **IMPORTANT** – Ensure there is no contact with any of the internal parts of the terminal box.

- Briefly reconnect the mains power supply to the pump – the 'power on' light should illuminate if the pump has been correctly wired.
- Isolate the mains electrical power supply from the pump.
- Re fit the terminal box lid ensuring no cables are trapped.
- Re fit the four terminal box lid retaining screws, tighten to 0.8 Nm.




Fig. 10 Wiring removed for clarity

Note: This image is for reference only.

8.14 **Environment Protection:** Your appliance contains valuable materials which can be recovered or recycled.  
At the end of the products' useful life, please leave it at an appropriate local civic waste collection point.

# 8 YOUR 1 YEAR GUARANTEE

Congratulations on purchasing a Stuart Turner pump.

We are confident this pump will provide many years of trouble free service as all our products are manufactured to the very highest standard.

All Jet Pressure Sets are guaranteed to be free from defects in materials or workmanship for 1 year from the date of purchase.

Within the guarantee period we will repair, free of charge, any defects in the pump resulting from faults in material or workmanship, repairing or exchanging the whole unit as we may reasonably decide.

Not covered by this guarantee: Damage arising from incorrect installation, improper use, unauthorised repair, normal wear and tear and defects which have a negligible effect on the value or operation of the pump.

Reasonable evidence must be supplied that the product has been purchased within the guarantee term prior to the date of claim (such as proof of purchase or the pump serial number).

This guarantee is in addition to your statutory rights as a consumer. If you are in any doubt as to these rights, please contact your local Trading Standards Department.

In the event of a claim please telephone **'TechAssist'** or return the pump and flexible hoses with the accessories removed e.g pipes etc. If you have any doubt about removing a pump, please consult a professional.

**+44 (0) 800 31 969 80**

Proof of purchase should accompany the returned unit to avoid delay in investigation and dealing with your claim.

You should obtain appropriate insurance cover for any loss or damage which is not covered by Stuart Turner Ltd in this provision.

Please record here for your records.

TYPE NO.	SERIAL NO.	DATE PURCHASED
----------	------------	----------------

## NOTES

## NOTES



## DECLARATION OF CONFORMITY

### **Machinery Directive – 2006/42/EC**

BS EN 12100, BS EN 809

### **Low Voltage Directive – 2014/35/EU**

BS EN 60335-1, BS EN 60335-2-41

### **EMC Directive – 2014/30/EU**

BS EN 55014-1, BS EN 55014-2, BS EN 61000-3-2, BS EN 61000-3-3,  
BS EN 61000-4-2, BS EN 61000-4-3, BS EN 61000-4-4, BS EN 61000-4-5, BS EN 61000-4-6,  
BS EN 61000-4-11

### **EMF Directive – 1999/519/EC**

BS EN 62233

### **RoHS Directive – 2011/65/EU**

### **WEEE Directive – 2012/19/EU**

IT IS HEREBY CERTIFIED THAT THE STUART ELECTRIC MOTOR DRIVEN PUMP AS SERIAL  
NUMBER BELOW, COMPLIES WITH THE ESSENTIAL REQUIREMENTS OF THE ABOVE E.E.C.  
DIRECTIVES.

\_\_\_\_\_

( \_\_\_\_\_ )

( \_\_\_\_\_ )

\_\_\_\_\_

RESPONSIBLE PERSON  
AND MANUFACTURER

STUART TURNER LIMITED  
HENLEY-ON-THAMES, OXFORDSHIRE  
RG9 2AD ENGLAND.

Signed .....  ..... Engineering Manager

Stuart Turner are an approved company to BS EN ISO 9001:2015



Stuart Turner Ltd, Henley-on-Thames, Oxfordshire RG9 2AD ENGLAND  
Tel: +44 (0) 1491 572655, Fax: +44 (0) 1491 573704  
info@stuart-turner.co.uk www.stuart-turner.co.uk