

ACCESSORIES

Top Entry Flange Fitting Instructions

1. Isolate cold supply to the hot cylinder and rising main.
2. Drain down the hot water
3. Remove existing fittings from the top of the cylinder
4. Clean cylinder flange top to ensure a good seal
5. Fit the cylinder flange to the cylinder ensuring both the sealing washers are correctly located
6. Orientate the outlet connection in the desired direction and carefully tighten up assembly
7. Re-connect the open vent and original hot water draw off pipe to the top using the G1 female connection and a suitable fitting (not supplied)
8. Connect the secondary air free supply using the G3/4 female connection and a suitable fitting (not supplied)
9. Ensure all drain cocks are closed and all fittings are tight
10. Restore the cold water supply to the hot cylinder
11. Check carefully for leaks before leaving unattended

Stuart Turner Ltd, Henley-on-Thames, Oxfordshire RG9 2AD ENGLAND

Tel: +44 (0) 1491 572655

Fax: +44 (0) 1491 573704

info@stuart-turner.co.uk www.stuart-turner.co.uk