


BILLY





Riser rail assembly



Installation Instructions

INSTALLERS PLEASE NOTE THESE INSTRUCTIONS ARE TO BE LEFT WITH THE USER

FITTING THE RISER RAIL ASSEMBLY



WARNING!

Check there are no hidden cables or pipes before drilling holes for wall plugs. Use great care when using power tools near water. The use of a residual current device (RCD) is recommended.

Decide the position for the rail on the wall within the shower area. Proceed as follows:

Offer the upper bracket to the wall. Position the bracket then mark the centre hole. (*The wallplugs provided are suitable for most brick walls – use an appropriate masonry drill, but if the wall is plasterboard or a soft building block, you must use special wallplugs and an appropriate drill bit*).

Fit the spacer onto the bracket if required. Replace the bracket and spacer to the wall and secure in place using the screw supplied (**Fig.1**).

Slide the riser rail into the recess in the lower bracket (**Fig.2**).

With both parts to hand, slide the riser rail through the opening in the upper bracket (**Fig.3**). The riser rail should protrude through the top bracket by a minimum of 4mm. Make sure the rail is vertical then mark the centre hole for the lower bracket. Remove the rail and lower bracket. Drill and plug the wall.

Fit the showerhead holder onto the riser rail. Turn the lever anti-clockwise to release the locking mechanism, then slide the holder onto the rail (**Fig.4**). To secure the holder in place, turn the lever clockwise.

Slide the soapdish and hose retainer onto the bottom of the riser rail, below the holder (**Fig.5**).

Refit the lower bracket to the riser rail. Take the riser rail/lower bracket assembly and again slide it through the upper bracket.

Note: The hole in the bottom of the riser rail should align with the opening in the lower bracket.

FITTING THE RISER RAIL ASSEMBLY (CONTINUED)

Secure the lower bracket to the wall using the screw supplied.

Note: The screw should pass through the hole in the base of the riser rail (**fig.6**) to stop it from turning within the bracket.

Fit the end caps onto both brackets. The end caps will only fit one way. Fit the riser rail trim to the top of the rail.

FITTING THE HOSE AND SHOWERHEAD






Feed the flexible hose through the hole in the hose retainer (**fig.7**) (Water Regulations).

Screw the flexible hose to the shower outlet and showerhead, making sure the supplied washers are in place at both ends of the flexible hose (**fig.8**).

Place the showerhead into the holder and check that it fits correctly (**fig.9**).

Note: The holder is slightly tapered and the showerhead and hose will only fit from one direction.


IMPORTANT: It is the conical end of the hose which grips into the holder. The showerhead will not fit in the holder without the hose attached.



SPARE PARTS

Ref. Description	Part number
-------------------------	--------------------

- Kit (without riser rail)	88900017
A Brackets & trims (pair) - <i>white</i>	83312110
B Trim (single) - <i>white</i>	83312120
C Riser rail – 25 mm - <i>stainless steel</i>	88800011
D Showerhead holder - <i>white/grey</i>	83312130
E Soap dish - <i>clear</i>	83308420
Soap dish - <i>Grey</i>	83312160
F Hose retainer - <i>white</i>	83312140
G Optional spacer - <i>white</i>	83312150
- Flexible hoses available in the following sizes:	
• 1.00 m in white, chrome and gold	
• 1.25 m in white, chrome and gold	
• 1.75 m in chrome only	



Please refer to shower installation and operating instructions for service details

TRITON reserve the right to change product specification without prior notice. E&OA. © TRITON PLC 2008